


LEVEL 2 DONNING for an UNSTABLE or WET suspect patient or CONFIRMED patient with viral hemorrhagic fever at BCH-Oakland

<p>The healthcare worker (HCW) who will care for the patient:</p> <ul style="list-style-type: none"> • Will wear surgical or disposable scrubs (shirt tucked in) and washable/wipeable footwear • Will pre-hydrate and use the restroom • Appropriately secure hair low and tight so that it is off the neck and back, and out of eyes/face • Remove jewelry, badge and other loose items including watches • Secure glasses, if needed • Verbally acknowledges each command given by observer 	<p>Supplies Needed:</p> <ul style="list-style-type: none"> • Alcohol-based Hand Rub • Powered air-purifying respirator (PAPR) with shroud hood design that extends to shoulders and covers neck • Single-use AAMI Level 4 impermeable gown extending to at least mid-calf • Single-use outer apron • Single-use boot covers extending to at least mid-calf • Inner standard gloves • Outer extended cuff gloves (must fit over inner gloves so may need size up) • Chair for donning boot covers
<p>The trained observer (must be present):</p> <ul style="list-style-type: none"> • Does not need PPE during the DONNING process • Reads the steps aloud to the HCW in a step-by-step fashion during the donning process • Visually confirms that all PPE is donned correctly • Assures that all skin, hair, and clothing is covered 	

Prior to donning:	Verified
<p>1. INSPECT: The trained observer and the HCW ensure that all PPE and supplies are available and that the sizes selected are correct for the HCW. Unfold each item and visually inspect to ensure that there are no rips or tears. Ensure the apron is a proper length; if adjustment is needed for a shorter length, trim the apron as necessary.</p>	<input type="checkbox"/>
<p>2. PREPARE PAPR HELMET:</p> <ol style="list-style-type: none"> Review the VERSAFLO training video (also accessible using the QR code to the right). Turn on the PAPR and check the airflow. Remove the plastic covering over face shield. Attach the shroud to the PAPR breathing hose. 	
<p>3. REVIEW: Review the donning sequence with the HCW before beginning the donning process.</p>	<input type="checkbox"/>

Donning sequence: <i>Observer Reads Aloud</i>	
<p>1. DON BOOT COVERS: Don the boot covers. Secure the ankle strap. Make sure that all areas of the shoes are covered, and the cover is snug.</p>	<input type="checkbox"/>
<p>2. HAND HYGIENE: Use hand sanitizer. Allow hands to dry.</p>	<input type="checkbox"/>
<p>3. PUT ON INNER STANDARD GLOVES: Ensure glove cuffs as far up arm as possible.</p>	<input type="checkbox"/>
<p>4. DON GOWN: Ensure gown is large enough to reach below the top of the boot covers. Ensure cuffs of inner gloves are under the sleeves of the gown. Observer helps secure all ties in the back.</p>	<input type="checkbox"/>
<p>5. DON HAIR COVER: Don hair cover. It should cover all hair and the ears.</p>	<input type="checkbox"/>
<p>6. DON PAPR HELMET AND SHROUD: PAPR with extended belt-mounted blower must have the blower and tubing on the outside of the gown to ensure proper airflow.</p>	<input type="checkbox"/>

7. DON OUTER APRON: Carefully pull over the PAPR hood to prevent breakage and ensure PAPR shroud remains tucked under the apron. Observer should disconnect and reconnect the hose to the shroud to ensure the neck of the apron does not tear with head movement. The observer can help secure the apron tie in the back.	<input type="checkbox"/>
8. PUT ON OUTER EXTENDED CUFF GLOVES: Don each glove. Observer assists by pulling the cuffs over the sleeves of the gown as far up the arm as possible.	<input type="checkbox"/>
9. INSPECT: Verify integrity of the PPE ensemble by having the person go through a range of motion.	<input type="checkbox"/>